

铜版纸157克
1140*140mm

FRESH ELEMENT SMART PET FEEDER


INSTRUCTION BOOK



PARTS



PARTS



INSTALL

1 CONNECT ADAPTOR
Take out the main machine, plug the power source adaptor into the power input, found under the main machine.

2 INSTALL
1. Place the base on a level surface.
2. Please make certain that the main machine power input and base connect are correct.

3 INSTALL BACKUP BATTERY
1. Remove screws to open the battery cover.
2. Install 4 D-cell alkaline batteries in battery compartment. Make certain the bucket is empty and that there is no food in the bucket when you install or change the battery.
3. Upon battery installation, please calibrate. Press and hold the manual feed button until the food outlet door opens. You will hear a short beeping sound to indicate that the machine is ready for calibration. (Attention: if there is food inside, empty the container). Calibration is complete when you hear a long sound.
4. For every time install and remove batteries, please repeat steps 1, 2, and 3 to calibrate. Otherwise, the rest food indicator may affected.

HOW TO USE

OPEN THE LID
Move release key to the left to open the lid of the food storage bucket.

FILL WITH FOOD
Fill with dry pet food after completing above steps.

PUT DESICCANT IN
Open desiccant package and flatten the desiccant evenly inside the small orange box.

MANUAL FEED
Click the manual feed button and the food outlet door will open and start to feed. Click the manual feed button again and the outlet door will close, completing the feeding process.

SMART PLAN FEED
Download the PETKIT app in the App Store or Google Play. Once downloaded, add and link your equipment and set up your feeding plan. Open up the PETKIT app and click "+" to add your equipment. Follow the prompt to set up feeding plan for your pets.

BASIC PARAMETERS

Name	PETKIT SMART FEEDER
Product model	PS12
Size	Main machine: 221 x 217 x 423mm Base: 445 x 223 x 50mm
Dry cell batteries	4 D-cell alkaline batteries
Recommended pet type	small to medium size dogs/cats
Total weight	5kg
Wireless	Wi-Fi enabled
Nominal voltage	6 VDC
Rated power	6W 1000Ma

ERROR DIAGNOSIS

Wi-Fi indicator light flashing	Smart feeder offline: First check your network connection. If network is stable, open the PETKIT app and tap the top right corner button to reset the Wi-Fi.
Food storage indicator light keeps flashing	System error: Ensure that lid is tightly closed. Then reset the smart feeder.

Note: To manage other issues or perform daily maintenance, please check the electronic directions.

NOTES

Failure in complying with these instructions may lead to equipment malfunction or pet's safety concern

- For dry pet food only.
- PLEASE place base on a level surface.
- DO NOT put anything (except dry pet food) into the bucket. Foreign objects will cause equipment to malfunction or lead to pet's safety concern.
- It is recommended to place equipment in a corner or against the wall. Please place at least 70mm distance between the base and the wall, however.
- DO NOT allow pets to bite the wire. It may cause an electric shock or death.
- DO NOT allow children under the age of 12 control or play with this equipment.
- DO NOT touch the food outlet door once the food is out.
- DO NOT put anything on top of the machine. Anything against the machine may affect the machine's function.
- PLEASE KEEP the bucket empty if you wish to take it out.
- For dog and cat use only. We DO NOT recommend any pet under the age of 3 months use this equipment.

ELECTRONIC DIRECTIONS



Scan to download electronic directions
<http://m.petkit.com/product/handle.html?product=01>

We will improve our product regularly to offer you the better product. May has difference between the real product and package photo.



项目名称	PETKIT	部 件		版 本	v1.0	日 期	20170822
设计师	叶满			审 核			